

# Public Address System

Portable and powerful PA system both mains and battery operated.

Complete with 2 hand held radio microphones and one radio neck mic.

Can play music etc. from a USB and has connections from iPhone etc.



# Read Me!

**Keep the switch and button pressers away!**

Check bag contents overleaf

## **Notes:**

- 1) Charge battery before use
- 2) Microphones can only use two channels at any one time, use:  
1 x Red + 1 x Blue = OK  
1 x Red + 1 x Red = is not possible
- 3) Aerials are delicate – take care of them

**Start-up** – Refer to diagram on page 4 of the instructions

- 1) Turn Volume & Echo & Mic Volume anti clockwise (Off)
- 2) Switch power On
- 3) Switch VCV volume Off
- 4) Switch Vol A & Vol B (Mic Volume) anti clockwise (Off)
- 5) Press VHF On/Off button – LED will light up
- 6) Switch on each microphone in turn, increase Vol A & Vol B for each mic to obtain required volume

**Shut Down** – refer to diagram on page 4 of the instructions

- 1) Switch off all microphones
- 2) Switch off units power
- 3) Pack microphones and power lead etc. into bag
- 4) Check bag contents (see overleaf)
- 5) Attach bag to unit and return to store



**Contents checklist overleaf:**



## Contents:

**If any of the following are missing or damaged let District MPRC know asap or you may be charged for replacements!**

- 1) This checklist
- 2) Instruction booklet
- 3) Two Radio Microphones (1 x Blue & 1 x Red)
- 4) One Radio Microphone body pack unit (Red)
- 5) One Neck Microphone for the body pack unit
- 6) One Lapel Microphone for the body pack unit
- 7) Unit power lead with protective pin cover

**See Read Me overleaf:**